

Dräger FPS® 7000 RP

The new Dräger FPS® 7000 with RP connection for combination with the Dräger PSS® BG4 closed circuit breathing apparatus offers the highest degree of safety for use in mining and by the fire service.



DRÄGER FPS® 7000 RP

Fire in tunnels or subway shafts are extreme situations, which demand maximum resilience from man and material. Even today, mining and tunnel construction are associated with great risks and dangers. Simply following legal guidelines, regulations and standards is no guarantee of safety. The Dräger FPS® 7000 full-face mask sets new standards in terms of safety and wearing comfort. The new design offers a large, optimized field of vision, while the availability of multiple different sizes ensures the mask fits comfortably and securely.

Field of vision and mask body

The mask body, which is made of either hypoallergenic silicone or EPDM, provides an especially comfortable fit. The enhanced field of vision offers a larger angle of vision thanks to the distortion-free polycarbonate visor. The anti-scratch coating almost completely prevents wear caused by wiping the visor.

Fit

The full-face mask Dräger FPS® 7000 has an outstanding head and face fit. The

ergonomic head harness and double sealing line ensure a secure and comfortable fit on all face shapes and contours.

Mask-helmet combination

The Dräger FPS® 7000 also achieves greater safety thanks to its newly developed adapter. For example, when combining the Dräger HPS 6200 fire fighting helmet with the new full-face mask, the newly developed and patented Dräger Q-fix connection prevents the unintentional release of the attachment.

Modularity

The mask can also be selected and configured in accordance with the particular demands of the user, in order to provide the necessary protection. Upon request, the mask can also be equipped with a hydration system, which allows the wearer to take on liquids during longer periods of usage.

Maintenance

The simple maintenance of all mask parts make the Dräger FPS® 7000 not only very economical and easy to service, but also flexible and versatile in its use.



Dräger FPS® 7000 RP

TECHNICAL DATA

DRÄGER FPS® 7000 RP

Mask body	Hypoallergenic and flexible silicone, or EPDM (dermatologically tested)
Head harness	5-point connection with large contact surface area at back of head, alternatively a hairnet
Mask-helmet combination	2-point connection for Dräger HPS 6200, either with Dräger Q-fix (with safety button) or with Dräger S-fix (without safety button) connection
Size of mask body	In 3 sizes (S, M and L), compatible with inner mask in 3 different sizes
Visor	Polycarbonate visor with anti-scratch coating
Connector	RP (Dräger connection for closed-circuit breathing apparatus)
Weight	approx. 600 g (varies according to version)
Approval	EN 136 Class 3 / EN 145

ORDER INFORMATION

Dräger FPS® 7000 RP

Dräger FPS® 7000 RP-EPDM-M2-PCas-CR	R 56 326
Dräger FPS® 7000 RP-EPDM-M2-PCas-S-fix	R 56 671
Dräger FPS® 7000 RP-Si-M2-PCas-Si	R 56 672

*Additional versions are also available. Please contact your sales representative for additional information.

PCas – Polycarbonate visor with anti-scratch coating; CR- Chloroprene; Si- Silicone;

S-fix: Mask-helmet combination with standard connection



Dräger Safety AG & Co. KGaA

Revalstrasse 1
23560 Luebeck, Germany
Tel +49 451 882-0
Fax +49 451 882-2080
www.draeger.com

P. R. CHINA

Beijing Fortune Draeger
Safety Equipment Co., Ltd.
Beijing 101300
Tel +86 10 80 49 80 00
Fax +86 10 80 49 80 05

NETHERLANDS

Dräger Safety Nederland B.V.
Edisonstraat 53
2700 AH Zoetermeer
Tel +31 79 344 46 66
Fax +31 79 344 47 90

SPAIN

Draeger Safety Hispania S.A.
Calle Xaudaró 5
28034 Madrid
Tel +34 91 728 34 00
Fax +34 91 729 48 99

SUBSIDIARIES

AUSTRALIA

Draeger Safety Pacific Pty. Ltd.
Axxess Corporate Park
Mt. Waverley, Vic 3149
Tel +61 3 92 65 50 00
Fax +61 3 92 65 50 95

CANADA

Draeger Canada Ltd.
7555 Danbro Crescent
Mississauga, Ontario L5N 6P9
Tel +1 905 821 8988
Fax +1 905 821 2565

FRANCE

Dräger Safety France S.A.S.
3c, Route de la Fédération
67025 Strasbourg Cedex
Tel +33 388 40 76 76
Fax +33 388 40 76 67

MEXICO

Draeger Safety S.A. de C.V.
Av. Peñuelas No. 5
Querétaro, Qro México
Tel +52 442 246 1113
Fax +52 442 246 1114

SINGAPORE

Draeger Safety Asia Pte. Ltd.
67 Ayer Rajah Crescent # 06 03
139950 Singapore
Tel +65 68 72 92 88
Fax +65 67 73 20 33

REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd.
P.O.Box 68601
Bryanston 2021
Tel +27 11 465 99 59
Fax +27 11 465 69 53

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside Business Park
Blyth, Northumberland NE24 4RG
Tel +44 1670 352 891
Fax +44 1670 356 266

USA

Draeger Safety, Inc.
101 Technology Drive
Pittsburgh, PA 15275
Tel +1 412 787 8383
Fax +1 412 787 2207